


TRISTAR 400 RCB

Code: 45400



Elenco pezzi di ricambio / Liste pieces detachees Spare parts list / Ersatzteilliste Piezas de repuesto / Список запасных частей




No	Desc	Code	pcs per box
1	Pannello / Panel / Panneau / Verkleidung / Panel панель	S404532SP	3
2	Commutatore 4 pos / 4 pos switch/ Umschalter 4 Pos. Commutateur 4 pos / Conmutador 4 pos / Коммутант положение 4	M480700SP	5
3	Mantello destro / Right mantle / Rechter Mantel / Capot droit / Capa derecha / Хламида части	S458020SP	1
4	Presse dinse / Dinse connection / Dinseanschluss Connexion dinse / Conexion dinse / Динсе связи	M431135SP	10
5	Ruota anteriore girevole / Front revolving wheel Drehendes Vorderrad / Roue antérieure tourne / Rueda anterior girato / Переднее колесо	M400290SP	6
6	Mantello sinistro / Left mantle / Linker Mantel / Capot gauche / Capa izquierda / нижней части	S458030SP	1
7	Commutatore 8 pos / 8 pos switch/ Umschalter 8 Pos. Commutateur 8 pos / Conmutador 8 pos / Коммутант положение 8	M480600SP	5
8	Commutatore 3 pos / 3 pos switch/ Umschalter 3 Pos. Commutateur 3 pos / Conmutador 3 pos / Коммутант положение 3	M480650SP	5
9	Cordone di alimentazione / Power cord Zufuehrungsschnur / Cordon d'alimentation / Cordon de alimentacion / Электрический провод	M587500SP	5
10	Coppiglia / Block wheel / Blockrad / Roue de bloc Rueda del bloque / Колесо блока	M908100SP	20
11	Ruota posteriore fissa / Fix back wheel/axle wheel Fixiertes Hinterrad / Roue postérieure fixe / Rueda posterior fija / Заднее колесо	M402700SP	6

TRISTAR 400 RCB

Code: 45400




Elenco pezzi di ricambio / Liste pieces detachees Spare parts list / Ersatzteilliste Piezas de repuesto / Список запасных частей



No	Desc	Code	pcs per box
12	Piastra term. / Term. slab / Terminalplatte / Galette term. Losa term. / терминальный сляб	M438310SP	3
13	Ponte raddrizzatore / Rectifier bridge / Gleichrichter Pont redresseur / Puenet rectificador / Мост выпрямителя тока	M784662SP	2
14	Induttanza / Inductance / Induktanz / Inductance Inductancia / Индуктивность	S755760SP	1
15	Trasformatore di potenza / Power transformer Leistungstransformator / Transformateur de puissance Transformador de potencia / Трансформатор мощности	S704660SP	1
16	Ventola / Roue à aubes / Impeller / Luefter Impeledor / Вентилятор	M504010SP	2
17	Golfari / Hook / Haken / Crochet / Gancho / Крюк	M896100SP	10

ACCESSORI / ACCESSORIES / ZUSATZGERÄTE

ACCESSOIRES / ACCESORIOS / ВСПОМОГАТЕЛЬНОЕ ОБОРУДОВАНИЕ



No	Desc	Code	pcs per box
18	Pinza porta elettrodo / Electrode holder Elektrodenhalter / Pincee porte electr / Pinza de elect/Держатель электрода	M615660SP	2
19	Pinza massa / Earth clamp / Massenklemmplatte Pince masse/Струбцина земли	M615100SP	2